

FILE NO.


SERVICE MANUAL


LCDTV


LCD-27XR1/AU


PRODUCT CODE No. 1 682 340 57 : Australia


















































PARTS LIST -

REF.No.	PARTS No.	DESCRIPTION	Q'TY	REMARK
Α	XI780X18W01C0	Front Cabinet Assy	1	
В	XI6152050301	Speaker	1	Right
С	XI6152050201	Speaker	1	Left
D	XI667L27U2520	Power Assy	1	
E	XI667L27W1815	Sound Processing Assy	1	
F	XI667L27W1840	TV Board Assy	1	
G	XI667L27W1869	Digital Processing Assy	1	
Н	XI780X18RHAF2	Back Cabinet Assy	1	
I	XI3603004200	Power Button	1	
J	N.S.P.	Stand Assy	1	
K	N.S.P.	Panel	1	
	XI01IL27W1802F	Remote Control	1	
	XI04L27W18S303	User Manual	1	

N.S.P.:No Service Parts



^{*} Only the parts in above list are used for repairing.
* Other parts except the above parts can't be supplied.